## Rocksoft

Print date: 04/05/2024



| Special cover   |   |
|---|---|
| Tissue paper converting : marrying laminate   | or roller   |
| Recommended solution for lamination without   | out glue, or with limited use of glue   |
| Recommended solution in case of a varying same machine  | number of plies produced on the   |
| Recommended solution for toilet paper cons  | sisting of 4 or 5 plies   |
| 55, 67 Shore D  |   |
| min. 10 mm - max. 20 mm   |   |
| Dry: cor  | ntinuous 80°C / peak 90°C   |
| Special multi layer cover with deformable ba<br>polyurethane top layer, allowing a perfect di   |   |
| Outstanding abrasion resistance, extended lifetime  |   |
| Adapts to varying machine settings and wor  | king pressure   |
| Allows more versatility on the converting line amount of plies (2 to 5)   | e, uniform lamination whatever the  |
| Longer residual time in the nip helps to pres lamination  | serve the alignment of the plies during   |
| Makes it possible to reduce the quantity of glamination, preserving the softness of the pa  |   |
| Makes it possible to increase the line speed  |   |
| Avoids back-side embossing and preserves  | the thickness of the laminated paper  |
| Easy to clean   |   |
| Acid solutions: Alkaline solutions: Hot water and steam: Ozone: Oil and grease: Aromatic solvents (toluene, benzene,): Chlorinated solvents: Polar solvents (MEC, ether, acetate,): | Moderate<br>Good<br>Not suited<br>Good<br>Very good<br>Not suited<br>Not suited<br>Not suited   |
|   | Tissue paper converting: marrying laminator Recommended solution for lamination without Recommended solution in case of a varying same machine  Recommended solution for toilet paper consistence and |

Alcohols (ethanol, IPA,...):

HANNECARD YOUR ROLLER EXPERT

Good

## Rocksoft

| Recommended cleaning products: | (Tepid) water, soap, industrial cleaners, cleaning fuel, terpentine, with limited use : alcohol |
|--------------------------------|---|
| Remark:                        | 55 shore D = 98 shore A   |



Print date: 04/05/2024